



Lp	Kod	Nazwa	Ilość
A-01	485400	throttle Lever	1
A-02	485401	Screw	2
A-03	485402	throttle fixed plate	1
A-04	485403	throttle cable	1
A-05	485845	Choke cable	1
A-06	485405	Bolt	2
A-07	485404	Plate	2
A-08	485433	Screw	4
A-09	485434	Pulley Sleeve	1
A-10	485435	Belt Pulley	1
A-11	485436	Spring	1
A-12	485437	clutch	1
A-13	485438	Sleeve	1
A-14	485439	Washer	1
A-15	485440	Blade Bolt	1
A-16	485683	Screw	3
A-17	485408	Nut	5
A-18	485414	Clamp	2
A-19	485413	Oil Pipe	1
A-20	485411	Sleeve	2
A-21	485416	Flat Washer	9
A-22	485415	Bolt	2
A-23	485410	Fuel tank bracket	1
A-24	485409	Screw	1
A-25	485417	Bolt	1
A-26	485407	Fuel tank	1
A-27	485406	Tank cover	1
A-28	485424	Insulation board	1
A-29	485423	Screw	2
A-30	485425	Bolt	8
A-31	485426	Spring washer	6
A-32	485432	muffler cover	1
A-33	485427	Bolt	2
A-34	485428	Spring washer	2
A-35	485429	Flat Washer	2
A-36	485430	muffler fiexed plate	1
A-37	485846	muffler	1
A-38	485471	Nut	4
A-39	485428	Spring washer	4
A-40	485844	right exhaust Pipe	1
A-41	485419	Washer	2
A-42	485843	left exhaust Pipe	1
A-43	485854	LC2P73F engine	1
A-44	485850	Meshes	1
A-45	485441	Key	1
A-46	485710	Tie	2
B-01	485443	Bolt	1

B-02	485444	Swing arm assembly	1
B-03	485445	Nut	12
B-04	485446	Tensioning wheel assembly	1
B-05	485429	Flat Washer	3
B-06	485448	Spring	1
B-07	485408	Nut	7
B-08	485450	Fixed plate	1
B-09	485425	Bolt	4
B-10	485452	Screw	2
B-11	485453	Fixed plate	1
B-12	485454	Plate	1
B-13	485455	Nut	2
B-14	485456	Screw	2
B-15	485457	Micro switch support bracket	1
B-16	485458	pedal	1
B-17	485459	pressure plate	4
B-18	485409	Screw	8
B-19	485461	plate	1
B-20	485462	Nut	3
B-21	485463	Bolt	1
B-22	485464	Nut	2
B-23	485465	Idler assembly	2
B-24	485466	Sleeve	2
B-25	485467	Washer	2
B-26	485468	Bolt	2
B-27	485469	pedal	1
B-28	485470	Spring	1
B-29	485471	Nut	3
B-30	485426	Spring washer	2
B-31	485473	Hexagonal joint	1
B-32	485474	Flat Washer	1
B-33	485475	Split Pin	3
B-34	485476	Tie rod assembly	1
B-35	485477	Wheel cover	2
B-36	485478	Split retaining ring	2
B-37	485479	Washer	2
B-38	485480	Washer	2
B-39	485481	Wheel	2
B-40	485482	Washer	2
B-41	485483	Flat Key	2
B-42	485484	Fixed plate	1
B-43	485485	Bolt	2
B-44	485486	Bolt	1
B-45	485487	Bolt	4
B-46	485488	Lever	1
B-47	485489	Split Pin	1
B-48	485416	Flat Washer	1
B-49	485491	Transmission	1
B-50	485492	Pin	1
B-51	485493	Spring	1

B-52	485494	Lever	1
B-53	485495	Pedal	1
B-54	485496	Pedal	1
B-55	485497	Walking pedal assembly	1
B-56	485498	Reverse gear switch pressure plate	1
B-57	485499	Screw	2
B-58	485500	Bolt	1
B-59	485501	Idler assembly	1
B-60	485502	Sleeve	1
B-61	485503	Fixed plate	1
B-62	485504	Pin	1
B-63	485505	Brake Lever	1
B-64	485506	Limit wire clamp	1
B-65	485507	Sleeve	1
B-66	485508	Parking push rod	1
B-67	485509	Spring	1
B-68	485510	Parking board	1
B-69	485511	Bolt	1
B-70	485512	Belt	1
C-01	485513	Bumper	1
C-02	485409	Screw	10
C-03	485515	Support frame assembly	1
C-04	485423	Screw	28
C-05	485517	Split Pin	2
C-06	485518	Left Bracket	1
C-07	485519	Right Bracket	1
C-08	485520	frame assembly	1
C-09	485425	Bolt	15
C-10	485522	Foot pedal left front fixing plate	1
C-11	485523	Foot pedal right front fixing plate	1
C-12	485408	Nut	9
C-13	485525	Left foot cushion	1
C-14	485526	Left floor panel	1
C-15	485527	Right floor panel	1
C-16	485528	Right foot cushion	1
C-17	485529	Fixed plate	1
C-18	485530	Nut	10
C-19	485531	Bolt	2
C-20	485462	Nut	2
C-21	485533	U-shaped protective frame	1
C-22	485534	Fixed plate	1
C-23	485535	Bolt	1
C-24	485536	pressure plate	1
C-25	485537	pressure plate	1
C-26	485452	Screw	2
C-27	485539	Nut	2
C-28	485540	Fixed plate	1

C-29	485455	Nut	4
C-30	485542	Nut	1
C-31	485543	Screw	1
C-32	485544	Bolt	10
C-33	485545	Nut	20
C-34	485546	extension plate	2
C-35	485547	Fixed plate	1
C-36	485548	Fixed plate	1
C-37	485549	Rear Plate	1
C-38	485550	Spring	2
C-39	485551	Bolt	2
C-40	485552	Hook	2
C-41	485553	Fixed plate	1
C-42	485554	Fixed plate	1
C-43	485555	Fixed plate	1
C-44	485556	Bolt	6
C-45	485557	Seat bracket assembly	1
C-46	485558	Nut	4
C-47	485559	Support plate	1
C-48	485560	Support plate	1
C-49	485561	Strengthening plate	1
C-50	485562	Strengthening plate	1
C-51	485563	Fixed plate	2
C-52	485564	Left bracket assembly	1
C-53	485565	Right bracket assembly	1
C-54	485566	Cushion	1
C-55	485567	Bolt	4
C-56	485568	Nut	4
C-57	485569	Screw	2
C-58	485570	Left positioning board	1
C-59	485571	Right positioning board	1
C-60	485572	Fixed plate	2
C-61	485487	Bolt	4
C-62	485574	Nut	2
C-63	485575	Bolt	4
C-64	485576	Shock-absorbing pads	2
D-01	485577	Bolt	2
D-02	485578	D-shaped universal ball joint assembly	2
D-03	485579	Left steering linkage rocker arm assembly	1
D-05	485581	Right steering linkage rocker arm assembly	1
D-06	485477	Wheel cover	2
D-07	485478	Split retaining ring	2
D-08	485584	Flat Washer	4
D-09	485585	Washer	4
D-10	485586	Wheel	2
D-11	485587	Left front wheel axle assembly	1

D-12	485588	Right front wheel axle assembly	1
D-13	485589	Left steering linkage	1
D-14	485574	Nut	2
D-15	485591	Bearing	2
D-16	485592	GREASE FITTING	2
D-17	485593	Front axle assembly (with shaft sleeve)	1
D-18	485594	Flat Washer	4
D-19	485595	Bolt	1
D-20	485596	Flat Washer	2
D-21	485597	Sleeve	1
D-22	485598	Spring washer	1
D-23	485599	Nut	1
D-24	485600	connecting rod	1
D-25	485601	Bolt	1
D-26	485428	Spring washer	2
D-27	485429	Flat Washer	4
D-28	485604	Steering wheel connector sleeve	1
D-29	485605	steering column jacket	1
D-30	485606	Steering wheel shaft	1
D-31	485607	Pin	1
D-32	485608	Steering wheel teeth	1
D-33	485609	Pin	1
D-34	485610	Washer	2
D-35	485611	Ball cover pressure plate	1
D-36	485612	Steering ball sleeve	1
D-37	485613	Lock Ring	1
D-38	485409	Screw	2
D-39	485615	Bolt	2
D-4	485580	Nut	6
D-40	485616	Bolt	4
D-41	485617	Steering gear bearing seat	1
D-42	485618	Screw	3
D-43	485619	Screw	1
D-44	485620	Steering gear assembly	1
D-45	485621	Sleeve	1
D-46	485468	Bolt	1
D-47	485545	Nut	2
D-48	485624	Steering wheel Cover	1
D-49	485625	Steering wheel	1
D-50	485626	Washer	2
D-51	485627	Flat Washer	1
D-52	485628	Nut	2
D-53	485489	Split Pin	1
E-01	485544	Bolt	1
E-02	485428	Spring washer	3
E-03	485632	Flat Washer	2
E-04	485633	pulley assembly	2

E-05	485634	Bearing	4
E-06	485635	Flat Key	2
E-07	485636	Pulley shaft	1
E-08	485637	Blade pully base	2
E-09	485445	Nut	17
E-10	485639	Bolt	8
E-11	485640	dust cover	2
E-12	485641	Lock Ring	2
E-13	485642	Flat Key	2
E-14	485643	Blade holder assembly	2
E-15	485852	T102 Left Blade	1
E-16	485645	Washer	2
E-17	485646	Blade Bolt	1
E-18	485853	T102 Right Blade	1
E-19	485839	Belt AA Li2388	1
E-20	485486	Bolt	2
E-21	485429	Flat Washer	2
E-22	485501	Idler assembly	2
E-23	485652	Sleeve	2
E-24	485653	Bolt	1
E-25	485471	Nut	2
E-26	485655	Cleaning connector	2
E-27	485851	Welding assembly	1
E-28	485657	Bolt	2
E-29	485658	4-inch guide wheel	2
E-30	485659	Flat Washer	2
E-31	485660	Bolt	1
E-32	485661	Flat Washer	1
E-33	485662	Tensioning wheel assembly	1
E-34	485663	Sleeve	1
E-35	485664	tensioning wheel swing arm assembly	1
E-36	485665	Fixed plate	1
E-37	485666	Spring	1
E-38	485667	Bolt	1
E-39	485668	Nut	2
E-40	485669	Bolt	1
E-41	485670	axle	1
E-42	485671	Blade Bolt	1
E-43	485823	Screw	3
F-01	485673	Handle	1
F-02	485674	Lever	1
F-03	485675	Bolt	1
F-04	485530	Nut	9
F-05	485677	Flip rod plug	1
F-06	485678	280L Fabric bag	1
F-07	485679	Handle Cover	1
F-08	485680	Grass catcher upper cover	1
F-09	485681	Screw	2
F-10	485682	bracket assembly	1

F-11	485683	Screw	8
F-12	485684	Sleeve	2
F-13	485685	branch pipe	1
F-14	485415	Bolt	4
F-15	485687	branch pipe	2
F-16	485688	Screw	4
G-01	485689	headlight wire	2
G-02	485690	"o" Ring $\phi 11.2 * \phi 1.6$	2
G-03	485691	Nut	4
G-04	485692	Wire assy	1
G-05	485693	Wire assy	1
G-06	485694	relay	1
G-07	485695	Switch	1
G-08	485696	Key	2
G-09	485697	Wire assy	1
G-10	485698	Wire assy	1
G-11	485699	Battery	1
G-12	485700	Wire assy	1
G-13	485701	Switch	2
G-14	485702	wire	1
G-15	485703	Switch	2
G-16	485704	wire	1
G-17	485705	Wire assy	1
G-18	485706	PCB card	1
G-19	485707	Screw	4
G-20	485847	Wire assy	1
G-21	485709	Tie	19
G-22	485710	Tie	2
G-23	485412	Oil Pipe Fixing Clip	4
G-24	485712	Charger	1
G-25	485713	Display	1
G-26	485714	Switch	1
G-27	485715	Sleeve	1
G-28	485716	PCB card	1
H-01	485717	grass plug component	1
H-01-01	485718	compression rod	1
H-01-02	485719	rope	1
H-01-03	485720	Handle Plug	1
H-01-04	485721	Lever	1
H-01-05	485722	Nut	1
H-01-06	485489	Split Pin	1
H-01-07	485724	shaft	1
H-01-08	485725	Plug	1
H-01-09	485726	Spring	1
H-02	485727	Knob	2
H-03	485728	Rear grass tube	1
H-04	485729	Front grass tube	1
H-05	485530	Nut	2
H-06	485731	Sleeve	2
H-07	485732	Bolt	2

I-01	485580	Nut	12
I-02	485734	Flat Washer	13
I-03	485735	Lever	2
I-04	485736	Bolt	2
I-05	485459	pressure plate	4
I-06	485409	Screw	8
I-07	485739	BRACKET ASSEMBLY	1
I-08	485517	Split Pin	1
I-09	485475	Split Pin	4
I-10	485742	Raise hexagonal joint	3
I-11	485574	Nut	6
I-12	485744	Lever	1
I-13	485745	connecting rod	1
I-14	485746	BRACKET ASSEMBLY	1
I-15	485747	hexagonal joint	1
I-16	485748	Lever	1
I-17	485591	Bearing	1
I-18	485750	Bolt	2
I-19	485751	Adjusting rod	2
I-20	485626	Washer	4
I-21	485753	Lever	1
I-22	485754	Handle	1
I-23	485653	Bolt	1
I-24	485756	Spring	1
I-25	485545	Nut	1
I-26	485758	arm bracket	1
I-27	485759	Height adjust board	1
I-28	485760	Washer	6
I-29	485423	Screw	2
I-30	485762	Spring	1
I-31	485763	Spring	1
I-32	485764	Lever	1
I-33	485765	Bolt	1
I-34	485464	Nut	3
I-35	485594	Flat Washer	2
I-36	485628	Nut	1
J-01	485769	Front Cover	1
J-02	485681	Screw	85
J-03	485771	Left bottom cover	1
J-04	485772	Right bottom cover	1
J-05	485773	Left side cover	1
J-06	485774	Right side cover	1
J-07	485775	Fix holder	1
J-08	485776	upper cover	1
J-09	485777	Left reflector	1
J-10	485778	Left lampshade	1
J-11	485779	Left lamp holder	1
J-12	485781	Right lampshade	1
J-13	485780	Right reflector	1
J-14	485782	Right lamp holder	1

J-15	485783	Upper cover	1
J-16	485784	Left Cover	1
J-17	485785	Right Cover	1
J-18	485786	Lift handle cover	1
J-19	485787	Logo pedestal	1
J-20	485788	Logo light	1
J-21	485789	Fan Cover	1
J-22	485848	Housing	1
J-23	485539	Nut	5
J-24	485792	Bolt	1
J-25	485423	Screw	2
J-26	485794	Cover	1
J-27	485795	Cover	1
J-28	485796	Battery pressure rod	1
J-29	485797	Cover	1
J-30	485849	Housing	1
J-31	485799	Vehicle armrest	2
J-32	485800	Cup holder	1
J-33	485801	Screw	8
J-34	485802	Left cover	1
J-35	485803	Body pedestal	1
J-36	485804	Right Cover	1
J-37	485805	Right cover	1
J-38	485806	Cover	1
J-39	485807	plate	1
J-40	485409	Screw	20
J-41	485809	Steering wheel base	1
J-42	485810	Housing	1
J-43	485811	Screw	2
J-44	485812	Bolt	4
J-45	485813	Fixed plate	2
J-46	485814	Screw	4
J-47	485815	bottom cover	1
J-48	485816	Left cover	1
J-49	485817	Right cover	1
K-01	485818	Seat	1
K-02	485819	Spring	2
K-03	485820	Nut	2
K-04	485821	Fixed plate	1
K-05	485822	Flat Washer	4
K-06	485823	Screw	4
K-07	485428	Spring washer	4
K-08	485825	Fixed plate	1
K-09	485826	Bolt	2
K-10	485827	Spring sleeve	2
K-11	485423	Screw	2
L-01	485829	wrench	2
L-02	485830	screwdriver	1
L-03	485831	wrench	1
L-04	485832	sleeve	1

L-05	485833	wrench	1
L-06	485834	funnel	1
L-07	485835	funnel	1
L-08	485836	fuse	1
L-09	485837	fuse	1