

Model:LC192F		Code Number:T199006835-0008000	LC/LT-2023-A
No.	Part No.	Description	Reqd. QTY
1	380140077-0005	Hexagon bolt with flange	9
2	120230190-0001	Cylinder head cover	1
3	380741427-0001	Breather tube	1
4	110850029-0001	PACKING, BREATHER CHAMBER	1
5	110840040-0001	CAP,BREATHER CHAMBER	1
6	380140039-0003	Hexagon bolt with flange	6
7	120250054-0001	Gasket for cylinder head cover	1
8	380140337-0001	Hexagon bolt with flange	4
9	380180099-0001	Stud	2
10	180650113-0001	Outlet gasket	1
11	180572669-0001	Muffler	1
12	270960014-0001	Spark plug	1
13	120080789-0001	Cylinder head	1
14	120150249-0001	Gasket for cylinder head	1
15	380600116-0001	ocation pin	2
16	140510059-0001	Valve rocker shaft	2
17	140450069-0001	Valve rocker combination	2
18	140320002-0001	Valve adjustment cap	2
19	140390015-0001	Valve locker	4
20	140380021-0001	Retainer, valve spring	2
21	140340025-0001	Inner spring of valve	2
22	140360010-0001	Seat, valve spring	1
23	140400012-0001	Valve oil seal	1
24	500550063-0001	Valve Kit	1
25	380140005-0006	Hexagon bolt with flange	7
26	380650337-0001	Oil seal	2
27	110820299-0001	Crankcase cover	1

Model:LC192F		Code Number:T199006835-0008000	LC/LT-2023-A
28	150290043-0001	Engine oil Strainer	1
29	171750045-0001	Components of governor gear	1
30	381150716-0001	Compression spring	1
31	380640016-0001	Steel ball	1
32	380600121-0002	ocation pin	2
33	380840925-0001	Seal ring	1
34	170870162-0001	Tank cover	1
35	170720009-0001	Pouring orifice filter screen combination	1
36	380950188-0001	Pipe clip	2
37	380620035-0001	Key	1
38	283690002-0001	Oil level alarm	1
39	281890014-0001	Engine oil protector	1
40	380140004-0004	Hexagon bolt with flange	2
41	150010136-0001	Components of oil pump	1
42	110830071-0001	Crankcase cover gasket	1
43	171680198-0001	Throttle handle combination	1
44	140670067-0001	Push rod	2
45	140690004-0001	Lifter, Valve	2
46	140020183-0001	Camshaft assy	1
47	130150143-0001	Connecting rod	1
48	130450051-0001	Balancing shaft	1
49	130290722-0001	crankshaft	1
50	380600119-0001	ocation pin	2
51	380840812-0001	Seal ring	1
52	171600151-0001	Governing spring	1
53	171620036-0002	Speed regulating bracket	1
54	380650339-0001	Oil seal	1
55	381350004-0001	Pin clip	1
56	171630003-0001	Speed regulating arm	1

Model:LC192F		Code Number:T199006835-0008000	LC/LT-2023-A
57	380450522-0001	Flat washer	1
58	110690097-0003	Oil rule combination	1
59	110810436-0001	Crankcase body	1
60	380340005-0005	Hexagon nut	2
61	380751166-0001	Oil tube	1
62	170501513-0001	Tank	1
63	160200073-0001	Side plate	1
64	110260024-0001	Sealing plug screw	1
65	380450516-0001	Flat washer	1
66	172840061-0001	Tank supporting bracket	1
67	172840062-0001	Tank supporting bracket	1
68	380140785-0001	Hexagon bolt with flange	4
69	380370007-0004	Hexagon nut with flange	2
70	380920086-0001	rubber flat gasket	2
71	380560057-0001	Steel cable baffle ring	2
72	130030290-0001	Piston	1
73	130060080-0001	Piston pin	1
74	130070251-0001	Piston ring combination	1
75	380180091-0001	Stud	2
76	170430062-0001	Carburetor gasket	1
77	170440080-0001	Heat insulating pad for carburetor	1
78	170430050-0001	Carburetor gasket	1
79	160190117-0001	air deflector	1
80	170022334-0001	Carburetor	1
81	171610025-0001	throttle return spring	1
82	171590054-0001	Throttle rod	1
83	170430070-0001	Carburetor gasket	1
84	180021071-0001	Air filter	1
85	380370048-0001	Hexagon nut with flange	2

Model:LC192F		Code Number:T199006835-0008000	LC/LT-2023-A
86	270920509-0001	COIL ASSY.,IGNNTION	1
87	380140103-0004	Hexagon bolt with flange	2
88	270020445-0001	FLYWHEEL COMP	1
89	160180041-0002	Impeller	1
90	193590039-0001	Starting disc	1
91	380370079-0001	Hexagon nut with flange	1
92	193490531-0003	Manual starting assembly	1
93	380140067-0003	Hexagon bolt with flange	6
94	380930027-0001	Location wire nail	1